



Ameri-Brand

Installation Help

1. Drain the water down to a level that is a couple of inches below where the Ameri-Shield will eventually hang.
2. Clean the area with a solution of dish washing liquid and warm water. This will help remove any oils and other contaminants that tend to float on the water and stick to the wall.
3. Dry the area with a towel.
4. Place the Ameri-Shield at the location where it is to be applied. Place the "T" Lock portion of the Ameri-Shield directly over the thin slot above the bead on your liner. Using a small block of wood and a hammer, place the wood directly on the "T" lock and "seat" the "T" Lock into the slot by tapping the block with the hammer.
5. Pull the lower edge of the Ameri-Shield up and expose the underside. Pour the adhesive onto it and using a brush, quickly smooth it out as evenly as time will allow.
6. Flip the glue coated Ameri-Shield down into place and using a clean rag, wipe it in a downward motion and apply a little pressure on the panel until it sets in place.

TIPS:

A: In some cases, for additional reinforcement, it's a good idea to cut a piece of the Ameri-Shield to fabricate a patch and glue it over the hole prior to installing the Ameri-Shield.

B: The adhesive (HH66) comes with a "dauber" attached under the lid in the can. It's difficult to apply an adequate amount of glue quickly enough using the dauber. Purchase a 2" (disposable) paint brush. Pour the glue onto the vinyl (like syrup on pancakes) and spread it quickly with the disposable brush.

C: Working with a foot or so of Ameri-Shield at a time makes the job easier.

D: Cut a small piece of Ameri-Shield off and then cut it into 2 pieces. Glue the 2 pieces together (one on top of the other) and you will get a feel for how the glue sets up.

E: The HH66 adhesive is clear when dry and will float on top of the water if any gets in the pool.